Instruction Manual

Carepeutic®

Bed Rest Lounger
with 2-speed vibration massage
and heated therapy

KH265

This user manual provides both operation information of this product and its detailed specifications. Please read this manual carefully and understand it thoroughly before operation.

FEATURES:

1) Vibration massage with two intensities.
2) With soothing heated therapy.
3) LED reading light, bendable for different reading spots.
4) Large side pocket for magazines, books, iPhone.
5) Built-in cup holder.
6) Built-in carrying handle, comes with carrying bag.
7) Detachable arms connected with built-in zippers, easy to assemble and disassemble for storage.
8) AC adaptor included.

OPERATION GUIDE:

1) Assemble the cushion with the left and right arms by using its built-in zipper.



2) Connect the power cord to the cushion, plug the AC adaptor to the wall outlet.

Control panel located at the side of back cushion

3) Turn on the power for reading light by pressing the On/Off button (optional).

4) Press the Massage Button to turn on vibration massage.

5) Press the Heat Button to turn on the heated therapy.



CAUTION:

- To avoid spilling over, we suggest that you do not put your drink in the cup holder during massage.
- To avoid overheated, please do not use the massaging function for more than 15 minutes continuously. Wait for the device to cool down for every 15 minutes use. It also has built in thermostat control for overheated protection. When the temperature reaches 158 Fahrenheit degrees (^{o}F), the massager will shut down automatically. Should this happen please wait for 45 minutes or more until the device is completely cool down before using it again.
- Do not use this product while you are sleeping.

- Never leave this product unattended while the power is connected.
- Keep the product clean and away from the wet environment or fireplace or heater.

IMPORTAN SAFETY INSTRUCTIONS

When using the product, all instructions and basic precautions should always be followed, including the following:

DANGER - To reduce the risk of electric shock:

Always unplug this product and its power adaptor from the electrical outlet immediately after use and before cleaning. Never leave this product unattended while the power is connected.

WARNING — To reduce the risk of burns, fire, electric shock, or injury to persons:

1) The product should never be left unattended when the power is plugged in. Unplug power adaptor from outlet when it is not in use and before putting on or taking off parts.
2) Do not operate this device under blanket. Excessive heating can occur and cause fire, electric shock, or injury to persons.
3) Close supervision is necessary when this product is used by, or near children, invalids, or disabled persons.
4) Use this product only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
5) Never operate this product if it is dropped, has a damaged cord or plug, a malfunction, or it is dropped into water. Return the product to service centre for examination and repair.
6) Do not carry this product by its supply cord or use cord as a handle.
7) Keep the cord away from heated surfaces.
8) Never operate the product closed to fireplace or heater.
9) Never drop or insert any object into any openings.
10) This product is only for indoor use. Do not use it outdoors.
11) Do not operate where aerosol (spray) products are being used or where oxygen is administered.
12) To disconnect, switch off all controls and remove plug from outlet.
13) The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or with the lack of experience and knowledge - unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.
14) Children should be supervised to ensure that they do not misuse the product.
15) Use all functions carefully. May cause serious burns. Do not use over insensitive skin areas or in the presence of poor circulation. The unattended use of this product by children or incapacitated persons may be dangerous.
16) Any individual who is pregnant, has a pacemaker, suffers from diabetes, or suffers from malignant tumors, excessive bleeding or tuberculosis should consult with a physician before using this device. This device is designed for home use only.

SAVE THESE INSTRUCTIONS

NOTE: This product is intended for household use only

After use:

When the product is not in use, switch off all functions to OFF position and the power adaptor should be unplugged from both massager and electrical outlet. Never leave this product unattended while the power is connected.

To clean and maintain the product

1. Cleaning

- Before you clean it, please make sure you switch all functions to OFF position and the power adaptor should be unplugged from both massager and electrical outlet.

- Please use dry cloth to clean the product.

Attention

• Please make sure that do not use benzene or thinner and other aggressive detergents to clean the product. Otherwise, it may cause damage to the product.

2. Maintenance

- When the product is not in use, switch all functions to OFF position and the power adaptor should be unplugged from both massager and electrical outlet.
- Keep the product clean and away from the wet environment or fireplace or heater.

3. More Safety Instruction:

Read the instruction manual thoroughly before using this product.
When using electrical products, specifically when children are present, basic safety precaution should always be followed, including the following:

- Always unplug the appliance's power cord from the electrical outlet immediately after using it and before cleaning it.
- Close supervision is necessary when this appliance is used by, close or next to children, invalids, or disabled person. This product should not be operated by child under age 12.
- DO NOT operate this appliance if it has a damaged power cord or damaged electric plug; if it is not working properly; and if it has been dropped or damaged or dropped into water. Return the product to service center for examination and repair. Never try to repair this device by yourselves.
- Keep power cord away from heated surfaces.
- The appliance should never be left unattended when it is connected to power source. Unplug the power cord from power outlet when it is not in use or before putting on or taking off parts.
- This device is NOT for outdoor use.
- DO NOT immerse this device in water or with any other liquid.
- To disconnect the power source, turn all controls to the off position on control panel, and then remove the plug from power outlet.
- Use this appliance only for its intended use as described in this manual.
- DO NOT use attachments that are not recommended by us with this device.
- DO NOT attempt to stand up on this device. Use it only when you are being seated and lean gently on the cushion.
- Connect this appliance to properly founded electric outlet only.
- This appliance is not intended for use by person (including children) with reduces physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction in regards to the use of the appliance by a person responsible

for their safety. Children should be supervised to ensure that they do not play with the appliance.

- DO NOT use the device in the bathing room or where you taking shower. Use it only in a dry area. Keep it away from humid area, wet floor. Do not spray water or liquid onto the massager or the outside areas around the appliance.
- If you have any concerns regarding your health, consult your doctor before using this appliance.
- DO NOT use this device continuously for more than 15 minutes at a time. Extensive use could cause overheated on the device. Should this occur, discontinue use and allow the unit to cool down before using it again.
- If you experience pain in a muscle or joint for a prolonged period of time, discontinue use and consult your doctor.
- Never use the appliance while sleeping by sitting down or lying down.

Specifications:

Rated Voltage: DC 12V
Rated Power: 9.5W

CE

Correct Disposal of this product
This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental sate recycling.

Limited Warranty

Please contact seller for warranty. Limited warranty from manufacturer only for original purchaser against defect related to manufacturing or workmanship under normal use.
Due to the hygiene or rehabilitation nature of this product, it is non-returnable.

Carepeutic™ is a trademark of Q.L.M., © all rights reserved
www.ideatomorrow.com